

TUNNEL MOVER ASSEMBLY INSTRUCTIONS

1.) When gluing PVC fittings use Heavy Duty Clear PVC Cement. Apply cement to the inside perimeter of the fitting, then in one motion insert the pipe to its full depth. The full depth of the pipe is 1.5". You may want to use a rubber mallet to ensure the pipe is fully inserted.

2.) Glue each of the 47.5" pieces to the base assembly.

3.) Glue the handle to each of the 47.5" pieces

4.) Glue each of the small legs into place. Make certain you have them in the proper location.

5.) Using a 3/4" wrench bolt each wheel in place. Do not over tighten. The wheel should spin freely.

