Clean RunPortable Pop-Up Tent Instructions

To Set Up Your Tent:

1. Remove the tent from the bag.* Unsnap the belt and remove the elastic band.



2. Unfold the tent and lay it out on the ground. Make sure the strings and material are free to move and not tangled.





3. Grab the handles of the strings in one hand and place the other hand on top of the plastic dome. Pull both strings at the same time until the tent pops up completely and locks in place.







To Collapse Your Tent:

- 1. Push gently on the lower part of the pop-up mechanism. Experiment with how much pressure is needed ahead of time so you'll be comfortable doing it at a trial.
- 2. Pull the four sides up and fasten the buckle.









^{*}Unzipping the gusset on the bag will make it easier to get the tent in and out of the bag. Zipping it up after putting the tent in the bag will make your bag more compact.