

OSLO 427 Instructions

Press **C** to locate **NORMAL TIME**.

Then, press **A** to view **calendar**.

Press **B** to view **Alarm Time**.

Press **C** to view **Stopwatch**.

Press **C** a second time to set **Alarm Time**.

Press **C** a third time to set **NORMAL TIME**.

Press **C** a fourth time to view **NORMAL TIME**.

Insert photo here.

STOPWATCH: From **NORMAL TIME**, press **C** once. All zeros should appear. If not, press **B** to reset to all zeros. If the stopwatch is running, press **A** to stop and press **B** to reset to all zeros.

SINGLE EVENTS: Press **A** to start. Press **A** to stop and **B** to reset.

MULTIPLE SPLITS: Press **A** to start. Press **B** to take split reading. Press **B** again to return to running time. Take as many splits as necessary by pressing **B**. Press **A** to Stop and **B** to reset.

First and Second Place Finish: Press **A** to start. Press **B** to take first place time and **A** to take second place time. Press **B** to display second place time and press **B** again to reset to all zeros.

After 30 minutes, the stopwatch will register in one (1) second increments.

Set ALARM TIME . . . From **NORMAL TIME**, press **C** twice. Alarm hours appear flashing. Press or hold **A** to advance alarm hours. Press **B**, Alarm minutes appear flashing. Press or hold **A** to advance alarm minutes. The alarm will be armed (i.e., set to go off) after alarm time is reset. Press **C** to return to **NORMAL TIME**.

Set NORMAL TIME and CALENDAR . . . from **NORMAL TIME**, press **C** three times. Seconds appear flashing. Press **A** to reset seconds to all zeros. Press **B**, minutes appear flashing. Advance minutes by pressing **A**. Repeat this procedure to set hours and day of the week.

Select 24 hour (H) or AM/PM display by pressing and holding **A** while setting hours. Return to **NORMAL TIME** at any time by pressing **C**.

ARM/DISARM ALARM, CHIME & SNOOZE

(1) From **NORMAL TIME**, press and hold **B**. Press **A** to arm (alarm symbol (Δ) appears) or disarm (alarm symbol disappears). When alarm sounds, silence by pressing **B**. Pressing **A** when alarm sounds will activate snooze alarm, causing alarm to sound again in five (5) minutes.

(2) While holding **B**, press **C** to activate the hourly chime (all day bars appear). When activated, the chime signal sounds at the start of each hour.