

Thank You!

Thank you for purchasing the knuckle lockers from Max 200 Performance Dog Equipment, Inc! We think that these lockers will be a welcome addition to your Weave-A-Matic setup.

To use your knuckle lockers, simply slide them onto the weave poles before you place the poles on the knuckle. Be sure to slide them on with the cut-out part facing down.

If you want to be able to tilt your weave poles, slide the knuckle locker up the pole and turn it in such a way that the solid side of the locker rests on the middle bolt of the knuckle. This will allow the knuckle to bend freely to any degree you desire.

To lock your knuckle in the upright position, turn the locker so that it slides down over the knuckle, the middle bolt should slide up into the cut-out area of the locker, thus preventing the knuckle from bending.

If you set up your weave poles in this manner, it will be simple to change from the Weave-A-Matic setup to the rigid pole setup in seconds.

Please feel free to call us with any questions – (800) 446-2920